

19795 Tablet-PC-Stativhalter

- Effizient und flexibel - die Tablet-Halterung mit 3/8" (5/8")-Anschlußgewinde
- Schreiben, lesen, surfen, Bilder und Videos betrachten
- Gleichermaßen geeignet für Bühne, Heim und Studio
- Für Tablets aller möglichen Hersteller – keine Bindung an bestimmte Marke
- Für Bildschirmgrößen (Höhe: 163 - 242 mm, Breite: 102 - 189 mm)
- Mit hilfreicher Skalierung für wiederkehrende Größeneinstellungen
- Mit Verstellmöglichkeiten die keine Wünsche offenlassen:
Tabletgröße, Neigungswinkel, Ausrichtung, Hoch/Quer

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben. Diese Anleitung informiert Sie über alle wichtigen Schritte bei Aufbau und Handhabung. Wir empfehlen, sie auch für den späteren Gebrauch aufzubewahren.

SICHERHEITSHINWEISE

Bitte beim Montieren des Tablet-PC sicherstellen, dass dieses gemäß dieser Anleitung im Halter sicher platziert und auf sicheren Sitz geprüft ist.

Für unsachgemäßen Gebrauch und die daraus entstehenden Folgen bzw. Schäden wird seitens K&M nicht gehaftet!

- Geeignete Stative verwenden - das setzt voraus:

ERSTMALIGES EINLEGEN des Tablet (2-9)


* Zahlenwerte der Skala sind nur Beispiel (Auswahl div. Tablets s. Beiblatt)

- Standfestigkeit, Tragkraft, zentrische Belastung,
- 3/8" (5/8")-Anschlußgewinde, z.B. K&M 199, 260, 260/1, 201A/2, 25680, 26085, 26125, 26150, 262, 26250
- den Tablet-PC sorgfältig platzieren und durch anziehen der Schrauben fixieren, anschließend auf sicheren Halt prüfen
- Halterung umsichtig handhaben; v.a. bei Änderungen der Einstellung (Neigung, Format)

AUFSTELLANLEITUNG

TABLET am STATIV BEFESTIGEN (1)

- 1 a. Rändelscheibe des Stativs bis zum Anschlag auf den Gewindestöcken drehen
- b. Tablet-Halter auf Gewindestöcken schrauben
- c. Rändelschraube mit der Halterung verspannen



ERSTMALIGES EINLEGEN des Tablet (2-9)

Viele Einstellungen sind möglich - finden wir die Passende

2 Zunächst alle drei Rändelstifte öffnen bis sichergestellt ist, dass in der Halterung genügend Platz für das Tablet ist

- 3 a. Oberen Haltearm lösen,
- b. max. ausfahren und
- c. Klemmschraube wieder festziehen

- 4 a. seitliche Haltearme lösen und diese...
- b. ...mit Hilfe der Skalen symmetrisch in eine ungefähre Position ausfahren,
- c. Beide Klemmschrauben wieder festziehen

- 5 Tablet probehalber in die Halteecken führen
- a. Tablet zu schmal: Haltearme wieder etwas einfahren (symmetrisch) bis es passt.
- b. Tablet zu breit: Haltearme weiter ausfahren (symmetrisch) bis es passt.
- c. Tablet passt, wenn die Halteecken ohne seitlichen Luftspalt anliegen.

- 6 a. Tablet in beide Halteecken einlegen...
- b. ...und oben anlegen und festhalten

- 7 Oberen Haltearm einfahren




- a. Klemmschraube lösen und Arm einfahren...
- b. ...bis das Tablet spielfrei eingefasst ist.
- c. Klemmschraube wieder festziehen

- 8 Tablet in den Halteecken sanft einklemmen durch Anziehen der Rändelstifte

- 9 Ihr Tablet sollte jetzt sicher positioniert sein.
Bitte vergewissern Sie sich, dass dem so ist.

 - a. Sitzt das Tablet spielfrei in den Halterungen?
 - b. Sind die drei Rändelgriffe fest angezogen?
 - c. Sind die drei Kunststoffflügel fest angezogen?

Falls nicht, bitte anhand der Punkte (2-8) korrigieren.



AUFSTELLANLEITUNG

ENTNEHMEN des Tablet (10-12)



10 Rändelstifte etwas lösen

11 Tablet festhalten u. oberen Haken ANHEBEN

12 Tablet herausklappen und ENTNEHMEN

Wenn Sie stets das gleiche Tablet verwenden, empfehlen wir, die eingestellten Haltearme in dieser Position zu belassen.

ENTNEHMEN des Tablet (10-12)



ERNEUTES EINLEGEN des Tablet (13-15)

ERNEUTES EINLEGEN des Tablet (13-15)




bei voreingestellten Haltearmen

13 Tablet in untere Halteecken einlegen

14 Tablet am oberen Haken anlehnen und sanft gegen drücken bis es einrastet

15 Rändelstifte anziehen bis das Tablet wieder sanft eingeklemmt ist

Anschließend Festsitz prüfen wie in 9 beschrieben.



BENUTZERHINWEISE und FUNKTIONEN

Das Tablet kann verstellt werden in Neigung & Format.

Zu diesem Zweck muss das Tablet nicht aus der Halterung entnommen werden.


NEIGUNG (16-18)

Das Tablet kann zwischen senk- und waagerechter Endstellung in jeder Position fixiert werden. Dazu:

16 Tablet halten und Flügelmutter etwas lösen
17 Tablet neigen wie gewünscht und...

18 ...Flügelmutter wieder festziehen

NEIGUNG (16-18)



FORMAT (19)



Die Halterung verfügt über eine 90°-Drehfunktion.

Dadurch kann das Tablet hochkant oder quer präsentiert werden.

19 Halterung nehmen und ins Quer- bzw. Hochformat drehen - oder in die Schräga!

BEACHTE: Unsichtbare Anschläge in der Halterung begrenzen die Verdrehung.


FORMAT (19)



ABMESSUNGEN (20)

ABMESSUNGEN (20)

Die Minimal- bzw. Maximalmaße können aufgrund ungünstiger Längen/Breiten-Verhältnisse des Tablets möglicherweise nicht erreicht werden.



TECHNISCHE DATEN / SPEZIFIKATION

Material	Halterung, Gelenk: Polyamid PA, PE, TPU Schrauben: Stahl, verzinkt
Traglast	Tablets Höhe: min. 163mm, max. 242 mm Breite: min. 102mm, max. 189 mm Tiefe: min. 5 mm, max. 11 mm
Maße	Transportmaße B x T x H: 180 x 99 x 123 mm
Karton	B x T x H: 254 x 104 x 150 mm
Gewicht	netto 0,245 kg, brutto 0,445 kg

FEHLERSUCHE (F) und BESEITIGUNG (B)

F: Halterung wackelt

B: Verschraubung mit Stativ prüfen, ggf. nachziehen (1)

F: Tablet sitzt nicht richtig

B: Position der seitlichen Haltearme korrigieren, so dass die Halteecken spielfrei am Tablet anliegen (2-9)

B: Achten Sie auf symmetrische Einstellung der unteren Haltearme (4,5)
Assymetrisch eingestellte Arme stören die Optik und gefährden den Halt des Tablets.

B: Tablet am oberen Haltearm nicht nur anlehnen, sondern korrekt einfassen (7,8).

B: Mindest- bzw. Maximalabmessungen beachten (20)

19795 Tablet PC stand holder

- Efficient and flexible - the Tablet Holder comes with a 3/8" (5/8") connection thread
- Write, read, surf, look at pictures or watch videos - made easy
- Equally suited for the stage, home and studio.
- For tablets of all manufacturers - not bound to a specific brand
- Screen sizes (Width: 163 - 242 mm, Height: 102 - 189 mm)
- Helpful settings for quick setup and adjustments
- Provides any number of adjustments:

Tablet Size, Adjustment Angle, Direction, Portrait/Landscape ATTACH Tablet to the STAND (1)

Thank you for choosing this product. The instructions provide directions to all of the important setup and handling steps. We recommend you keep these instructions for future reference.

SAFETY NOTES

When mounting the Tablet PC ensure that it is properly placed and secured according to the instructions. K&M is not liable in the case of improper use and associated consequences i.e. damages!

- Only use suitable stands - the prerequisites are: stability, weight bearing load, centered load, 3/8" (5/8") connection thread, e.g. K&M 199, 260, 260/1, 201A/2, 25680, 26085, 26125, 26150, 262, 26250

- Place the Tablet PC carefully in position and tighten the screws, then check that the Tablet PC is securely in place
- Handle the holder with care, in particular when adjusting settings (angle, format)


SETUP

ATTACH Tablet to the STAND (1)

- 1 a. Turn the stand's knurled disc as far as it will go onto the stand's threaded bolt
- b. Screw the Tablet holder onto the threaded bolt
- c. Tighten the knurled screw to the mount

FIRST TIME PLACEMENT of the Tablet (2-9)


* Scale settings are only examples (Selection of various Tablets see Supplementary Sheet)



FIRST TIME PLACEMENT of the Tablet (2-9)


Many settings are possible - identify the required settings

- 2 First open the three knurled pins until there is enough room to place the tablet
- 3 a. Release the upper support arm,
b. extend it out as far as it goes and
c. tighten the clamping screw.
- 4 a. Release side support arms and...
b. ...with the help of the scale symmetrically extend to a rough position,
c. tighten both clamping screws.




- 5 Place the tablet into the corner supports to ensure that it fits

- a. Tablet is too narrow: Retract the support arms a bit (symmetrically) until it fits.
- b. Tablet is too wide: Extend the support arms (symmetrically) until it fits.
- c. Tablet fits, if the corner supports do not show any space between the tablet and the holder when looking at it from the side.



- 6 a. Place the tablet in both corner supports...
b. ...and hold the tablet

- 7 Retract the upper support arm
 - a. Release the clamp screw and retract the support arm...
 - b. ...until the tablet is securely held in place.
 - c. Tighten the clamping screw.



- 8 Gently clamp the tablet into the corner supports by tightening the knurled pins
- 9 Your Tablet should be securely positioned now.

Please ensure that this is the case.

- a. Does the Tablet sit securely in the holder without any play?
- b. Are the three knurled handles properly tightened?
- c. Are the three plastic finger screws properly tightened?

If this is not the case, please refer to points (2-8).


SETUP

REMOVING the Tablet (10-12)

- 10 Loosen the knurled pins a bit
- 11 Hold the tablet and LIFT UP the catch
- 12 Flip out the Tablet and REMOVE

If you always use the same tablet, we recommend that the support arm settings remain in this position.

REMOVING the Tablet (10-12)




REPEATED PLACEMENT of the Tablet (13-15)

For previously set support arms

- 13 Place the tablet in the lower corner supports
- 14 Place the tablet into the upper catch and gently press until it clicks into place
- 15 Tighten the knurled pins until the tablet is gently pressed into place

Then check that the Tablet is secure as described in 9.



USAGE NOTES and FUNCTIONS

The angle and format of the tablet can be adjusted.


The (securely positioned) Tablet does not have to be removed from the holder.

ANGLE (16-18)

The Tablet can be adjusted to any final position by adjusting it vertically and horizontally. To do this:

- 16 Hold the Tablet and loosen the wing nut somewhat
- 17 Pick the position (vertical/horizontal) and...
- 18 ...re-tighten the wing nut.

ANGLE (16-18)




FORMAT (19)

The holder has a 90°-Twist Function.

The Tablet can be presented in landscape and portrait positions.

- 19 Take the holder and turn it to the landscape, portrait or tilted - position!
- NOTE- Hitches within the mount limit how far the holder can be turned.


FORMAT (19)



DIMENSIONS (20)

The minimum and maximum size cannot be achieved due to the Tablet's unfavorable length/width ratios.

DIMENSIONS (20)



TECHNICAL DATA

Material	Holder, joint: PA, PE, TPU Screws: Steel, galvanized
max. load	Tablets Height: min. 163 mm, max. 242 mm Width: min. 102 mm, max. 189 mm Depth: min. 5 mm, max. 11 mm
Dimensions	Transport dimensions W x D x H: 180 x 99 x 123 mm
Packaging	W x D x H: 254 x 104 x 150 mm
Weight	net 0.245 kg, gross 0.445 kg

FAULT-FINDING (F) and REPAIR (R)

F: Holder is unstable

R: Check that it is properly screwed into the stand, if needed tighten the screws 1.

F: Tablet is not securely in place

R: Correct the position of the side support arms, so that the corner supports are properly set on the Tablet without any play (2-8).

R: Ensure that the lower support arms setting are symmetrical (4,5).

Asymmetric setting of the support arms looks bad and does not ensure that the Tablet is securely held in place.

B: Do not only place the Tablet on the upper support arm, but be sure it clicks into place (7,8).

B: Observe the minimum i.e maximum dimensions